



TECHNICAL GUIDE

Caliper Cover, Gasket & Plate: Faults, Replacement, Care

Learn how caliper cover, gasket and plate faults develop on air disc brakes, how to diagnose leaks, replace the group correctly and extend its life.

On a heavy commercial vehicle, a brake caliper fault usually arrives at the workshop described as "the caliper is finished", yet once the unit is stripped in the field most of the trouble turns out to sit not outside the caliper but underneath its rear cover. A handful of water that has worked its way inside, a gasket that has lost its shape or a plate with a crushed corner can jam the adjustment mechanism within a few thousand kilometres and wear the pad on one side only. Written from the perspective of a workshop foreman and a brake technician, this guide explains what the caliper cover, gasket and plate group actually does, how it fails, the correct diagnostic sequence, the discipline required when removing and refitting it, and the maintenance habits that extend its service life.

 **TIP** — This document has been prepared by the VADEN technical team on the basis of heavy commercial vehicle disc brake service practice and OE manufacturer documentation. The values given here are general reference figures; for exact data such as tightening torque, clearance tolerance and service interval, the current OE service manual matching the vehicle's engine/chassis code takes precedence. Last updated: July 2026.

What Is the Caliper Cover, Gasket & Plate? Function and Operating Principle

The Caliper Cover, Gasket & Plate is a service group made up of the cover that isolates the internal mechanism of a heavy commercial vehicle disc brake caliper from water, salt and dust, the gasket that seals the joint between cover and housing, and the plate that spreads the clamping force from the piston/tappet across the back of the brake pad. It works at a typical actuator pressure of 6–8.5 bar and is generally renewed once every 2–4 pad sets.

On a modern heavy commercial vehicle the brake caliper is a floating mechanism that multiplies the thrust arriving from the actuator (brake chamber) through a lever-and-eccentric arrangement and transfers it to the pad through two tappets. The whole assembly runs inside the caliper housing, in a closed, grease-filled volume. The cover group closes off exactly that volume. The cover is not merely a "blanking plate": it is the first and often the only barrier separating the adjuster spindle, the one-way adjuster gear and the grease pocket from the outside environment.

The cover cannot do the sealing job on its own. The gasket seated between cover and housing — depending on the application a flat paper/elastomer gasket, a profiled sealing ring or an O-ring — fills the micro-irregularities of the mating face and establishes permanent surface contact under bolt load. The most common field mistake is reusing the gasket while the cover itself is still sound; once an elastomer gasket has been compressed it is permanently deformed and will not deliver the same seal on a second assembly.

The plate, by contrast, sits on the force side. In designs where the tappet ends press directly onto the pad backing plate, the plate converts point contact into surface contact and distributes the load, reducing crushing of the pad backing, wear at the tappet tip and vibration-induced noise. In some OE designs the plate also acts as a guide that fixes the position of the pad in its carrier. In short, the cover protects the inside, the gasket makes that protection leak-tight, and the plate

distributes the outside force evenly. Because each one determines the service life of the others, they are usually listed in the catalogue as a single repair group.

Which parts are included in the group?

- **Mechanism cover (rear cover):** the metal or composite cover that closes the rear opening of the caliper housing.
- **Cover gasket / sealing ring:** the static sealing element between cover and housing, mostly single-use.
- **Thrust plate:** the plate that distributes force between the tappet and the pad backing.
- **Guide/intermediate plate:** the thin plate that sets the position and clearance of the pad in its carrier.
- **Adjuster spindle cap and plug:** the small plug that closes the access point to the automatic adjustment mechanism.
- **Tappet boot and retaining ring:** the boot protecting the exposed part of the tappet, together with its retainer.
- **Cover bolts / screws:** generally torque-controlled and single-use in most applications.
- **Spring rings, clips and circlips:** the small fasteners holding the cover and boot in place.

In which OE caliper families does it appear?

On heavy commercial vehicles the geometry of the caliper cover, gasket and plate depends far less on the vehicle make than on the **caliper family** fitted to it. The families most frequently encountered in the field are the pneumatic disc brake calipers originating from Knorr-Bremse and Wabco; besides Mercedes-Benz, Volvo, MAN, DAF, Scania, Iveco and Renault Trucks tractor units, these families also appear on trailer axles such as BPW, SAF and Schmitz. The same tractor model may carry a different caliper family in different production years, and even between its front and rear axle. These names are given only as **application examples**; the correct part is identified not by a brand name but by the type label on the caliper housing and the OE number.

What effect does the cover group have on brake performance?

The cover group does not generate braking force directly, but it determines whether that force is delivered consistently. In a caliper that has taken in water, the adjustment mechanism corrodes; as the pad wears the mechanism can no longer take up the clearance, pedal travel increases and brake imbalance develops between the two wheels of the same axle. **ECE R13**, the binding framework for heavy commercial vehicle brake performance, defines axle-based brake balance and effectiveness requirements; loss of cover sealing is one of the silent reasons a vehicle drifts outside those requirements. On the static sealing side, general standards such as **ISO 3601** are used as a reference for O-ring size and tolerance families. The applicable standard and material class may vary with the caliper family; exact data must be verified from the OE catalogue for the part.

Cover, gasket and plate design by caliper type (application comparison, general reference)

Caliper type / application	Cover design	Gasket type	Characteristic service note
----------------------------	--------------	-------------	-----------------------------

Caliper type / application	Cover design	Gasket type	Characteristic service note
Single-tappet pneumatic disc brake (tractor front axle)	One-piece metal mechanism cover	Profiled elastomer ring	Cover bolts torque-controlled, gasket single-use
Twin-tappet pneumatic disc brake (tractor rear axle)	Cover plus separate adjuster spindle plug	Flat gasket or O-ring	Both tappet boots renewed together
Trailer axle disc brake (BPW/SAF type installations)	Metal cover with corrosion-protective coating	Elastomer ring	Road salt effect pronounced, coating integrity critical
New-generation calipers with composite covers	Reinforced polymer cover	Sealing lip integrated into the cover	Excess torque cracks the cover, torque wrench essential
Older-generation vehicles with drum brakes	No cover group fitted	Not applicable	Adjustment mechanism external, different maintenance regime

⚠ CAUTION — Caliper cover, gasket and plate parts look very much alike; a diameter or thickness difference of a few millimetres cannot be told apart by eye. Do not select the part by "vehicle model" alone: verify it by reading the type label on the caliper housing, the production year and, where possible, the OE number on the part you removed. A plate of the wrong thickness changes the pad clearance and locks the automatic adjustment mechanism in the wrong position from the very first application.

How do you recognise a Caliper Cover, Gasket & Plate fault?

Caliper Cover, Gasket & Plate faults rarely announce themselves with a sudden failure; they usually progress as a slow loss of sealing followed by a chain of secondary damage. Because most of the symptoms are filed under the heading "caliper fault", correct diagnosis starts with separating a problem in the cover group from a problem in the mechanism. The table below matches field symptoms with likely causes and the method used to confirm them.

Caliper cover, gasket and plate fault symptoms, likely causes and verification methods

Symptom	Likely cause	Check / verification
Grease leak behind the caliper, a dirty ring mark around the cover	Gasket fatigued or crushed, cover bolt loosened	Clean around the cover and inspect again after 200–300 km; check bolt torque
One side of the pad noticeably more worn (one-sided wear)	Plate distorted or of the wrong thickness, uneven tappet clearance	Measure the pad thickness difference between the two tappets with a caliper gauge; check plate flatness on a surface plate
Pedal travel increasing over time, brakes biting late	Water/dirt ingress, automatic adjustment mechanism unable to take up clearance	Open the adjuster spindle plug and check that the mechanism turns freely; measure pad clearance

Symptom	Likely cause	Check / verification
Metallic rattle when braking or squeal at low speed	Plate has developed play in its seat, clip/spring ring broken	Try moving the assembly by hand at the caliper without removing the wheel; visually check plate seating
Swelling, cracking or corrosion blistering on the cover	Cover coating damaged, moisture accumulated inside	Surface inspection without removing the cover; look for water/emulsion in the internal volume during removal
The two wheels on the same axle heating up differently	Mechanism stiff in one caliper, brake dragging	Measure the axle-based temperature difference with a non-contact thermometer after a road run
Tappet boot torn, rust marks at its tip	Boot aged or not fully seated during assembly	Squeeze the boot by hand to look for tears; clean the tappet tip and inspect the surface
Uneven wear returning shortly after new pads are fitted	Old plate reused or caliper guides seized	Measure the free movement of the caliper on its guides; compare plate thickness against a new part

Visual and hands-on preliminary diagnosis

The first step of diagnosis can be carried out without lifting the vehicle. A dark, oily, dust-laden ring in the rear area of the caliper is almost always gasket-related; on a pneumatic disc brake caliper, which contains no brake fluid, the only fluid that can escape is the mechanism grease. The most common field pattern is that the leak is deferred because it looks "minor" and the mechanism turns up seized a few months later. Flexing that can be felt when the cover surface is pressed with a finger, or coating that lifts easily with a fingernail, indicates that the cover needs to be renewed as well.

Confirming by measurement: pad clearance and thickness difference

The second step is measurement. The thickness of the two pads in the same caliper is measured separately with a caliper gauge; a clear difference means force distribution has been disturbed and suspicion points directly at the plate and the tappet clearance. Total clearance between pad and disc is specified by the manufacturer within a narrow band, and a value above that band is the clearest indication that the automatic adjustment mechanism is no longer working. The measurement result must always be compared with the figure in the vehicle's own service manual.

Internal volume inspection after removal

The third and most conclusive step is removing the cover. Once the cover is off, the colour and consistency of the grease inside is a diagnostic report in itself: if the grease is light and homogeneous, sealing has been maintained; if a milky-coffee coloured emulsion is visible, water has entered; a black, dry and grainy structure means the grease is thermally exhausted and has lost its protective quality. Wherever emulsion or rust marks are seen, the entire cover group — cover, gasket, plate, boot and fasteners — is renewed; the leaking part alone is not replaced.

How is the Caliper Cover, Gasket & Plate replaced? Step by step

Replacing the Caliper Cover, Gasket & Plate is an operation that requires the vehicle's brake system to be depressurised and made safe. The steps below describe a general service flow; the sequence and torque figures vary with the caliper family, and the vehicle's current OE service manual takes precedence.

⚠ CAUTION — Before working on the brake system, secure the vehicle on level, solid ground, chock the wheels, drain the air reservoir by the method described by the manufacturer and mechanically release the spring brake chamber. A pressurised chamber or a loaded spring releases sudden, heavy force during removal. Safety glasses, cut-resistant gloves and steel-toe footwear are mandatory; brake dust must not be inhaled, and extraction or wet cleaning must be used instead of a dry brush.

- 1 Secure the vehicle and depressurise the system:** fit chocks, raise the vehicle onto stands, bleed off air pressure in the order described by the manufacturer and mechanically release the spring brake chamber.
- 2 Remove the wheel and clean the area:** take off the rim, remove dust from around the caliper using extraction or wet methods rather than compressed air, and clean the heads of the bolts to be removed.
- 3 Record the pre-removal measurements:** measure and note the pad thicknesses, disc thickness and pad-to-disc clearance; these values are needed for comparison after assembly.
- 4 Remove the pads and retaining components:** take out the pad retaining spring and pins, remove the pads, lift the old plate out of its seat and note its orientation.
- 5 Remove the cover:** loosen the cover bolts in a crosswise sequence and in stages; do not prise the cover off with a screwdriver, and if necessary lift it at the release points specified by the manufacturer.
- 6 Assess the internal mechanism:** check the condition of the grease, the free rotation of the adjustment mechanism and the tappet surfaces; if there is corrosion or binding, the job goes beyond a cover group replacement and a caliper overhaul is required.
- 7 Prepare the mating faces:** remove old gasket residue from the housing and cover sealing face with a plastic scraper; do not use a metal scraper, abrasive paper or grinding, as every scratch on the surface is a new leak path.
- 8 Fit the new gasket and cover:** place the gasket into its dry, clean seat without twisting it; if the manufacturer specifies grease, use only the specified type and quantity, and never fix the gasket in place with adhesive.
- 9 Tighten the cover bolts to torque:** after seating the bolts by hand, tighten them crosswise, in two stages and with a torque wrench to the manufacturer's figure; renew any bolt marked as single-use.

- 10 Fit the new plate, boots and pads:** seat the plate in its housing the correct way round, fit the tappet boots fully together with their retaining rings, install the pads and retaining components; measure and record the pad clearance.
- 11 Pressurise and test the system:** raise the air pressure, check for leaks, apply the brakes several times to let the mechanism settle; after a controlled low-speed test drive, measure the axle-based temperature difference and confirm there is no leakage around the cover.

What are the most common mistakes when replacing the Caliper Cover, Gasket & Plate?

Most mistakes made when replacing the Caliper Cover, Gasket & Plate come not from the part but from haste; the job itself is short, but the margin for error is small. The points below cover the typical situations that bring the same vehicle back to the workshop a second time within a short period.

⚠ CAUTION — Do not reuse the old gasket. Once an elastomer gasket has been held under bolt load it undergoes permanent deformation; on a second assembly it cannot deliver the same surface pressure, and the resulting leak is usually noticed not within the first few hundred kilometres but several months later, when the mechanism has already been damaged.

- **Tightening the cover without a torque wrench:** an under-tightened cover leaks, while an over-tightened cover — composite ones in particular — cracks or distorts the mating face.
- **Tightening the bolts in sequence:** without crosswise, staged tightening the gasket is crushed on one side while a gap remains on the other.
- **Cleaning the surface with a metal scraper or abrasive paper:** every scratch in the gasket seat is a permanent leak channel; a plastic scraper and a suitable cleaner are enough.
- **Fixing the gasket with adhesive:** silicone or liquid gasket disturbs the designed sealing geometry and damages the surface during removal.
- **Using the old plate with new pads:** a fatigued plate distorts the wear plane of the new pad from day one and restarts one-sided wear.
- **Fitting the plate the wrong way round or in the wrong thickness:** pad clearance changes and the automatic adjustment mechanism starts working from a false reference.
- **Neglecting the tappet boot:** if the cover is renewed but the old boot is left in place, water now enters through the boot and the work is quickly undone.
- **Not checking the caliper guides:** a seized guide keeps producing uneven wear even when the cover group is faultless.
- **Replacing only the leaking side:** the two calipers on the same axle age under similar conditions; one-sided renewal increases the risk of brake imbalance.
- **Skipping measurement and a test drive after assembly:** the job is not complete until pad clearance and temperature difference have been measured.

⚠ CAUTION — On a caliper where emulsion, rust or a seized adjustment mechanism is found once the cover is removed, the job must not be closed with a cover group replacement alone. In that case the mechanism has already been damaged; a caliper overhaul or replacement should be considered, and the decision supported by a brake balance measurement on the vehicle.

Caliper Cover, Gasket & Plate technical values and check points

The figures given for the Caliper Cover, Gasket & Plate vary with the caliper family, the axle load and the emission/equipment generation. The tables below show the general reference ranges encountered in heavy commercial vehicle service; none of them replaces the OE value for a specific vehicle.

Caliper Cover, Gasket & Plate technical values (general reference)

Parameter	Typical range (general reference)	Unit	Note
Brake chamber operating pressure	6–8.5	bar	System reservoir is usually higher, chamber side sits in this range
System reservoir operating pressure	8–12.5	bar	Depends on the governor setting
Total pad-to-disc clearance (after adjustment)	0.6–1.1	mm	Varies with caliper family, OE value takes precedence
Continuous operating temperature inside the caliper	80–200	°C	Peak values may be higher on long descents
Grease drop point (special grease used inside the caliper)	above 180	°C	Only the grease specified by the manufacturer is used
Pad service life (reference for cover group renewal interval)	80,000–200,000	km	Varies widely with the usage profile
Cover group renewal frequency	once every 2–4 pad sets	set	Renewed without waiting if leakage or emulsion is found

Tightening torque reference ranges (Nm, the OE service manual is authoritative for verification)

Joint	Typical torque range (Nm)	Note
Cover bolt / screw (small diameter)	10–35	Crosswise and staged tightening, upper limit critical on composite covers
Adjuster spindle plug	10–25	Over-tightening damages the plug and its seat
Pad retaining pin / spring fixing	15–40	Varies by application, mostly single-use
Caliper guide pin bolt	180–300	High torque, bolt usually single-use
Caliper-to-axle carrier fixing	250–450	Angle-controlled tightening may be required, OE procedure mandatory

 **TIP** — Torque figures vary with bolt diameter, material class and surface coating; the ranges given in the table are intended only to convey an order of magnitude. On brake joints, every bolt marked as single-use must be renewed, and tightening must always be carried out with a calibrated torque wrench.

Field check list after assembly:

- No trace of leakage around the cover, gasket line clean and uniform.
- Cover bolts tightened with a torque wrench and the values recorded.
- Pad-to-disc clearance measured and within the OE range.
- Thickness difference between the two pads in the same caliper at an acceptable level.
- Tappet boots free of tears, retaining rings fully seated.
- Caliper moves freely on its guides, no binding.
- No significant temperature difference between the two wheels on the same axle after the test drive.
- Brake performance verified on an axle basis on a brake tester where possible.

How is the Caliper Cover, Gasket & Plate maintained and its service life extended?

What determines the life of the Caliper Cover, Gasket & Plate group is not mileage alone but how much water and dirt get inside the caliper. On a tractor unit working on salted winter roads the same group wears out far sooner than on a vehicle operating in a dry climate. The maintenance plan should therefore be built around operating conditions rather than the calendar.

- **Assess the cover group at every pad change:** with the pads already removed, checking the cover, gasket, plate and boot takes a few minutes and costs no extra downtime.
- **Inspect the boots at periodic service:** a torn boot is the weakest link in the cover group and is a cheap part on its own.
- **Do not aim directly at the caliper when washing:** high-pressure water can defeat even a sound gasket; do not hold the jet nozzle close to the rear of the caliper.
- **Carry out an extra check after the road salt season:** at the end of winter the cover surface and coating integrity should be reviewed separately.
- **Use only the grease specified by the manufacturer:** the wrong grease runs at high temperature, leaves the mechanism unprotected and can swell the gasket.
- **Measure brake balance regularly:** axle-based differences in temperature and braking force are the earliest signal of a problem starting in the cover group.
- **Break the habit of postponing a leak:** the most common expensive scenario in the field is a small grease leak turning into a caliper overhaul a few months later.
- **Keep replacement records:** a record of when the cover group was renewed on which caliper makes life expectancy across the fleet realistic to estimate.

A correctly selected and correctly fitted cover group keeps the internal mechanism of the caliper dry and greased throughout the life of the pads. This group is a cheap service item, but when it is neglected the price is the caliper itself; that is why it is one of the small parts with the highest return in fleet maintenance.

Frequently Asked Questions

What happens if the caliper cover gasket leaks?

When the caliper cover gasket leaks, the grease in the internal volume escapes and water, road salt and dust take its place. At first only a dirty ring is visible behind the caliper; within a few months the automatic adjustment mechanism corrodes, pad clearance can no longer be taken up, pedal travel increases and brake imbalance develops between the two wheels on the same axle. Once a leak is noticed, the entire cover group must be renewed.

What is the purpose of the caliper plate?

The caliper plate spreads the force coming from the tappet across the pad backing plate, converting point contact into surface contact. This reduces crushing of the pad backing, wear at the tappet tip and vibration-induced noise during braking. In some designs the plate also acts as a guide fixing the position of the pad in its carrier, which is why its thickness and orientation directly affect pad clearance.

At what mileage is the caliper cover group replaced?

There is no fixed mileage figure for the caliper cover group; common field practice is to renew the group once every 2–4 pad sets. Because pad life ranges between 80,000 and 200,000 km depending on the usage profile, the real interval differs from vehicle to vehicle. If leakage around the cover, corrosion on the cover or emulsion in the internal volume is seen, replacement is carried out without waiting for a mileage figure.

Can an old caliper cover gasket be reused?

An old caliper cover gasket must not be reused. Once an elastomer gasket has been held under bolt load it undergoes permanent deformation and cannot provide the same surface pressure on a second assembly. The leak caused by a reused gasket is usually noticed not immediately but several months later, when the adjustment mechanism has already been damaged, turning the cost of a cheap part into a caliper overhaul.

What torque is used for the caliper cover bolt?

The caliper cover bolt is generally tightened within a range of 10–35 Nm depending on the application, crosswise and in two stages. This figure only gives an order of magnitude; the actual torque varies with bolt diameter, material class and cover material, and must be taken from the vehicle's current OE service manual. Because excess torque can crack a composite cover, a calibrated torque wrench is mandatory.

If there is water inside the caliper, is replacing only the gasket enough?

If water or a milky-coffee coloured emulsion is found inside the caliper, replacing the gasket alone is not enough. The water has already started corrosion on the adjuster gears and the

tappet surfaces; even with a new cover the mechanism will not regain its former precision. In this case the internal mechanism of the caliper must be inspected in detail and, if necessary, a caliper overhaul or replacement considered.

Can the caliper plate cause one-sided pad wear?

The caliper plate, if distorted, fatigued or chosen in the wrong thickness, prevents force from being distributed evenly across the pad surface and one-sided wear begins. However, the plate is not the only cause of one-sided wear; seized caliper guides, a damaged boot and a faulty adjustment mechanism produce the same symptom. For that reason, the free movement of the caliper on its guides must always be checked before replacing the plate.

Is the caliper cover group replaced on both wheels together?

The caliper cover group is recommended to be renewed on both sides of the same axle. Because the two calipers on an axle age under similar load, temperature and road conditions, when one starts to leak the other is also close to the end of its life. One-sided renewal creates different clearance and different response times between the two wheels, increasing the risk of brake imbalance.

How is the correct caliper cover, gasket and plate selected?

The caliper cover, gasket and plate part is selected by caliper family rather than by vehicle model. The correct approach is to read the type label on the caliper housing, verify the production year and, where possible, compare the OE number of the part removed. Because the front and rear axles of the same tractor unit may carry different caliper families, verification must be carried out on an axle basis.

Can compressed air be used to clean brake dust?

Using compressed air to clean brake dust is not recommended; the dust becomes airborne and creates an inhalation risk. The appropriate method is an extraction-type brake cleaning system or wet cleaning. Compressed air can also drive dirt into the boot and gasket seat, shortening the life of a newly fitted sealing element.

Within the VADEN ORIGINAL brake caliper product family, caliper cover, gasket and plate parts are offered across a broad range of references matched to the caliper families widely used on heavy commercial vehicle and trailer axles. Select the correct part by matching the caliper type label and the OE number; renewing the cover, gasket, plate and boot as a group rather than replacing a single item delivers both a longer service interval and safer brake balance.