



TECHNICAL GUIDE

Transmission PTO: Faults, Replacement and Maintenance Guide

A workshop guide to truck transmission PTO units: how they work, why they fail to engage, correct backlash setting on fitting and habits that extend life.

A tipper that will not raise its body, a concrete mixer stranded halfway through a job or a recovery truck whose crane arm refuses to deploy usually point to the same place: the small gearbox bolted to the side cover of the transmission. Known in the workshop as the power take-off unit, the drive take-off or simply the PTO, this component is the only bridge carrying engine power to the bodywork equipment, and when it fails the vehicle still drives but cannot do any work. Written from the point of view of a workshop foreman and service technician, this guide explains what a transmission PTO does, how it fails, the correct diagnostic sequence, the discipline required during fitting and the maintenance habits that extend its service life.

TIP — This document has been prepared by the VADEN technical team on the basis of heavy commercial vehicle driveline service practice and OE manufacturer documentation. The values given here are general reference figures; for exact data such as tightening torque, gear backlash, speed ratio and torque capacity, the current OE service manual matching the engine and transmission code of the vehicle takes precedence. Last updated: July 2026.

What Is a Transmission PTO? Function and Operating Principle

A transmission PTO (Power Take-Off, power take-off unit) is a gear unit bolted to the side or the rear of the transmission housing that takes its drive from the countershaft gear and transfers part of the engine power to bodywork equipment such as a hydraulic pump, tipper, mixer, crane or compressor. In heavy commercial applications the output speed is typically in the range of 50 to 140 percent of engine speed, while continuous torque capacity is in the order of 300–1,200 Nm depending on the model.

The transmission PTO goes by several names both in the workshop and in the catalogue: **power take-off unit, drive take-off, PTO box** or simply **power take-off**. Whichever name it is searched under, the selection criteria are the same: transmission type, output flange pattern and the required speed ratio.

The operating principle is built on a simple gear engagement. When the side cover of the transmission is removed, a gear on the countershaft becomes visible underneath. The PTO unit seats into this opening and its own input gear remains in permanent mesh with the countershaft gear. When the driver operates the switch in the cab, pressure from the vehicle air system is routed through a solenoid valve to the pneumatic piston inside the PTO; the piston pushes the sliding gear or the coupling sleeve towards the output shaft and the drive chain is completed. The flange on the output shaft then starts to turn the propshaft or the directly mounted hydraulic pump.

The critical point that is often overlooked is this: a classic side mount PTO takes its drive from the countershaft, and the countershaft turns at engine speed whenever the clutch is not depressed. That is why engagement is carried out with the engine running and the vehicle stationary. Clutch independent sandwich type units and split-shaft types mounted behind the transmission, on the other hand, are designed to transmit power while the vehicle is moving; these are common on mixers and road sweepers.

Which transmission families does it appear on?

What determines the compatibility of a transmission PTO is not the make of the vehicle but the **transmission family and the cover pattern** it is fitted to. On the heavy commercial side the most frequently encountered applications are the ZF Ecosplit and TraXon families, Mercedes-Benz G and GO series transmissions, Volvo I-Shift, Scania GRS/GRSO and gearboxes of Eaton origin. Different production years of the same tractor unit may use different cover patterns, so a PTO should never be ordered without first reading the type code on the transmission plate. The side cover interface is largely standardised across the industry: six and eight bolt hole patterns and output shaft spline profiles correspond to **ISO 7653** (transmission power take-off flange dimensions) and the **DIN 5462 / ISO 14** straight sided spline standards, while on the hydraulic pump side the **SAE J744** mounting interface is widespread. Since the applicable standard may vary by manufacturer and model, exact data must be verified from the OE catalogue for the part concerned.

Components and ancillary elements

- **Housing:** aluminium or cast iron, the main body that carries the gears and bolts to the transmission.
- **Input gear:** the element that meshes with the countershaft gear, its backlash being set during fitting.
- **Sliding gear or coupling sleeve:** the part that carries out the engagement and disengagement movement.
- **Pneumatic cylinder and piston:** the actuator that pushes the sleeve with air pressure.
- **Solenoid valve and air line:** the circuit that converts the signal from the cab switch into pressure.
- **Feedback switch:** the sensor that illuminates the indicator lamp and confirms engagement.
- **Output shaft and flange:** the power outlet connected to the propshaft or the pump.
- **Bearings, seals and gasket pack:** the consumable group that determines service life and sealing.

How do PTO types differ?

The speed, torque and duty cycle demanded by the application determine which type is selected. Short duty, high torque tipper work and mixer work that runs for hours on end cannot be covered by the same unit.

Transmission PTO types and typical application comparison (general reference; speed ratio is given as a percentage of engine speed)

PTO type	Mounting position	Typical speed ratio	Common application
Side mount, clutch dependent	Transmission side cover, 6 or 8 bolt	50-110 percent of engine speed	Tipper, hooklift, hydraulic lifting
Side mount high performance	Transmission side cover, reinforced housing	90-140 percent of engine speed	Crane, compaction refuse body, high flow pump
Rear mount	Transmission rear cover	80-110 percent of engine speed	Concrete pump, special bodywork

PTO type	Mounting position	Typical speed ratio	Common application
Sandwich type (clutch independent)	Between engine and transmission	Directly related to engine speed	Mixer, sweeper, operation while driving
Split-shaft (in-line)	On the propshaft line	Varies with the application	Fire pump, high power stationary duty

⚠ CAUTION — A transmission PTO is not selected on vehicle model alone. Even on the same tractor unit, the transmission type, cover hole pattern, direction of rotation, output flange form and required speed ratio lead to different part numbers. Before ordering, verify together the type code on the transmission plate, the OE reference number on the old unit and the speed and torque demanded by the bodywork equipment. If a PTO with the wrong ratio is fitted, the pump either delivers insufficient flow or is overspeeded and burns out in a short time.

How do you identify a transmission PTO failure?

Transmission PTO failures generally fall under three headings: failure to engage, failure to disengage, and mechanical noise with leakage. The first is mostly pneumatic or electrical, the third mechanical. The table below matches the symptoms most frequently met in the field with their likely causes and the way to verify them.

Transmission PTO symptom-cause-check table (field diagnostic sequence; pressure values are in bar)

Symptom	Likely cause	Check / verification
Cab switch is operated, the PTO does not engage at all, the indicator does not light	No air or no electrical supply reaching the solenoid valve; fuse, switch or line fault	Pressure measurement with a gauge at the solenoid outlet; check of the supply voltage with a multimeter; test of the fuse and cab switch
The indicator lights but the output shaft does not turn	The feedback switch is reporting a false position or the sliding gear has not fully engaged	Comparing the switch signal with actual rotation of the output shaft; verifying that air pressure is within the working range
Metallic grinding, crunching noise during engagement	Engaging before the clutch is fully depressed; engaging at high engine speed; worn sliding gear teeth	Repeating the engagement procedure at idle speed; removing the cover and checking the gear tooth ends for rounding and peening
Continuous whine in operation, noise rising with speed	Backlash set incorrectly, bearing fatigued or oil level dropped	Check of transmission oil level and colour; backlash measurement with a dial gauge; locating the noise source with a stethoscope
Oil leaking between the PTO housing and the transmission	Gasket pack crushed, bolt torque lost or the mating face scored	Leak tracing on a cleaned surface; rechecking bolt torques with a torque wrench
Oil dripping from behind the output shaft flange	Output seal hardened; propshaft angle incorrect, shaft running out	Visual inspection of the seal lip; measuring flange run-out with a dial gauge

Symptom	Likely cause	Check / verification
The PTO does not disengage, it keeps turning after the switch is closed	Air is not being exhausted, the piston has seized or the sliding gear is jammed in its seat	Listening for exhaust at the vent port; disconnecting the line and observing whether the piston moves freely
The unit overheats, the paint blisters	The continuous duty limit is exceeded, lubrication is insufficient or the unit is overloaded	Measuring surface temperature after operation with a non-contact thermometer; comparing bodywork running time against the records

Rule out the pneumatic circuit first

The quickest gain in diagnosis comes from eliminating the air circuit before looking for a mechanical fault. A pressure gauge is connected to the solenoid valve outlet, the switch is operated and it is checked whether pressure reaches the working range. If pressure is present, the problem is inside the unit; if it is not, attention turns to the switch, the fuse, the solenoid or the air line. It is no exaggeration to say that frozen moisture or a blocked air filter is the most common finding in the field; this check takes five minutes and prevents unnecessary removal work.

Mechanical verification by speed measurement

Measuring the actual speed of the output shaft with an optical or inductive tachometer shows both that engagement is complete and that the correct ratio unit is in use. When engine speed and output speed are compared, a figure clearly below the catalogue ratio means the coupling is not fully seated. This measurement also reveals whether the bodywork pump is running at the wrong speed.

Oil and swarf inspection

The level, colour and metal content of the transmission oil are the most honest indicators in PTO diagnosis. While fine metal dust on the magnetic plug is considered normal, bright flake shaped swarf points to gear damage. A low oil level means the input gear has been running without lubrication and can on its own be the cause of a whine.

How is a transmission PTO replaced? Step by step

Transmission PTO replacement is a half day job for an average workshop when it is carried out in the correct order; when the order is disturbed it creates secondary problems such as loss of transmission oil and incorrectly set backlash.

⚠ CAUTION — Before starting work, the vehicle must be parked on level ground, the ignition switched off, the parking brake applied and the wheels chocked. The bodywork load (tipper body, crane arm) must always be lowered or locked with a safety catch. The pneumatic line must not be disconnected before the air reservoir pressure has been released, and the battery terminal must be disconnected. Hot transmission oil carries a burn risk; the use of protective gloves, goggles and safety footwear is mandatory. Ensuring that auxiliary circuits fed from the vehicle air system do not weaken the brake circuits is a requirement of the protection valve logic covered by ECE R13; the air connection is never taken directly from the brake circuit.

- 1 Preparation and documentation:** Note the type code on the transmission plate, the OE number on the old PTO and the speed ratio. Photograph the air and electrical connections before disconnecting them; this is the step that saves the most time during reassembly.
- 2 Making the vehicle safe:** Switch off the ignition, disconnect the battery terminal, drain the air reservoir, lower the bodywork and chock the wheels.
- 3 Removing the propshaft or the pump:** Mark and remove the propshaft attached to the output flange. On a directly mounted hydraulic pump, prepare a support to carry the pump; leaving the pump hanging on the shaft under its own weight causes shaft and seal damage.
- 4 Disconnecting the pneumatic and electrical connections:** Label and disconnect the air line and the feedback switch connector. Cap the open line ends against contamination.
- 5 Managing the oil level:** If the PTO aperture is not above the oil level, drain the transmission oil into a suitable container. Depending on how the vehicle is standing, partial draining may be sufficient; the level datum in the service manual decides.
- 6 Removing the unit:** Slacken the bolts in a crosswise sequence and in stages. Do not try to pull the unit off directly; separate the housing with a slight rocking motion without damaging the mating face. Support its weight as you lift it away.
- 7 Checking the face and the gear:** Clean the old gasket residue from the transmission cover face without using a metal scraper. Inspect the tooth flanks of the countershaft gear for peening, pitting and broken teeth; if there is damage, replacing the PTO alone is not a solution.
- 8 Positioning the new unit:** Fit the new transmission PTO in place with the gasket pack supplied by the manufacturer. Do not use liquid sealant in place of the gasket; here the gasket thickness is also the adjusting element.
- 9 Setting the backlash:** Measure the clearance between the input gear and the countershaft gear with a dial gauge or by the lead wire method. If the measured value is outside the band specified by the manufacturer, adjust it by adding or removing gaskets. When this step is skipped, the unit either whines within a short time or the teeth are overloaded and break.
- 10 Torquing the bolts:** Tighten the bolts in a crosswise sequence, in stages and with a torque wrench to the value specified by the manufacturer. Keep the use of countersunk fasteners and washers as per the original.
- 11 Connections, oil and test:** Refit the air line, the connector and the propshaft; top the transmission oil up to level. Run the engine at idle, engage and disengage the PTO several times, listen to the noise and check for leaks. Then run the bodywork first unloaded and then loaded, measure the speed and check the housing temperature after a short period of operation.

What are the most common mistakes in transmission PTO replacement?

Transmission PTO replacements that fail early do so mostly because of fitting discipline rather than the part itself. The headings below are the causes most frequently found in the field on units that come back to the workshop for a second time.

⚠ CAUTION — Completing the assembly without measuring the backlash is the most expensive mistake that can be made on this job. If the clearance is left too small, the gears run permanently under load, heat up and progress to a tooth root fracture; if it is left too large, the tooth ends are peened under shock loading. In both cases the damage is not limited to the PTO, the countershaft gear also suffers and the job turns into a transmission strip-down.

⚠ CAUTION — Applying liquid sealant instead of the gasket pack looks like a practical solution but it destroys the adjustment logic. The gasket thickness is the very tolerance the manufacturer has left in order to hold the backlash band. In addition, excess liquid sealant can mix into the transmission oil and block the oil galleries.

- **Selecting a unit with the wrong speed ratio:** A PTO bought without calculating the speed the bodywork pump demands either delivers insufficient flow or overspeeds the pump and burns it out in a short time.
- **Tightening the bolts by hand or with an impact wrench:** Without a torque wrench the face pressure remains uneven; the unit either leaks or the housing cracks.
- **Engaging before the clutch is fully depressed:** This is the real cause of rounded gear tooth ends and of that characteristic crunching noise.
- **Engaging while the vehicle is moving:** On clutch dependent types this operating error ends in gear breakage. Operation while driving is valid only on types designed for that duty.
- **Handing the vehicle over without checking the transmission oil level:** If the oil lost during removal is not made up, the new unit runs dry.
- **Ignoring the propshaft angle and the pump weight:** An unsupported pump and an incorrect angle destroy the output shaft and the seal in a short time.
- **Taking the air supply from the brake circuit:** Auxiliary consumers must be fed from their own protected circuit; anything else directly endangers braking safety.
- **Reusing the old gasket, seal and single use items:** These parts do their job by being crushed during assembly and will not give the same sealing a second time.

Transmission PTO technical values and inspection points

Transmission PTO technical values vary across a wide band depending on the model, the housing material and the application class. The tables below summarise the typical ranges met in the field in heavy commercial applications; the exact value must always be taken from the service documentation for the unit and the vehicle.

Transmission PTO technical values (general reference)

Parameter	Typical range	Unit	Note
Engagement air pressure	6.0–8.0	bar	Vehicle system pressure is generally in the 8–12.5 bar range
Output speed (ratio to engine speed)	50–140	percent	Selected to suit the application; pump speed is the deciding factor
Continuous torque capacity	300–1,200	Nm	Varies by model according to housing and gear class
Momentary peak torque	1.2–1.5 times the continuous value	Nm	Short duty only, not valid under repeated loading
Input gear backlash	0.10–0.35	mm	Set with the gasket pack; measured with a dial gauge
Transmission oil operating temperature	80–100	°C	Continuous operation above 120 °C shortens oil life
PTO housing surface temperature (under load)	70–95	°C	A clearly higher value is a sign of overloading
Hydraulic pump working pressure (tipper application)	150–250	bar	The value given by the bodybuilder takes precedence
Oil change interval (transmission)	120,000–240,000	km	The lower limit is approached with heavy PTO use

Typical tightening torques for transmission PTO fitting (Nm, general reference bands)

Joint	Typical bolt size	Torque band (Nm)
PTO housing to transmission cover	M10, class 8.8	40–55
PTO housing to transmission cover	M12, class 8.8	70–95
Output flange nut	Model specific	120–200
Hydraulic pump mounting bolts	M10–M12	40–90
Propshaft flange bolts	M10–M12	60–110

TIP — The torque values in the table are intended only to give an order of magnitude. Bolt class, whether tightening is done dry or lubricated and the tightening sequence prescribed by the manufacturer change the result significantly. Always use a torque wrench, do not depart from the crosswise sequence and take the current service manual of the vehicle as the basis for the final value.

As a field checklist, the items below provide a quick verification both after fitting and at periodic maintenance:

- Measure at the solenoid outlet that the engagement pressure is within the working range.
- Measure the actual speed of the output shaft with a tachometer and compare it with the catalogue ratio.
- Check on a clean surface whether there is any leakage between the housing and the transmission and at the output seal.

- Review the transmission oil level and the amount of swarf on the magnetic plug.
- Measure the housing temperature with a non-contact thermometer after operation under load.
- Verify that the cab indicator lamp behaves correctly on engagement and disengagement.
- Recheck the torque of the propshaft flange bolts after the first week of operation.

How is a transmission PTO maintained and its service life extended?

Transmission PTO service life is determined mostly by operating habits rather than by the part itself. A correctly selected and correctly fitted unit can give a long service life with regular checks, while a poor engagement habit can finish the same unit off in a short time. The clearest difference observed in the field is between fleets whose drivers have been given brief operating training and those that have not.

- **Always engage at idle:** Engaging with the engine at idle speed and the clutch fully depressed is the single most effective habit for protecting the gear tooth ends.
- **Wait a few seconds after engagement:** Applying throttle before the sliding gear has been given the time it needs to seat fully creates shock loading.
- **Do not run it idle:** Leaving the PTO engaged while the bodywork is not working means unnecessary heat build-up and oil ageing.
- **Monitor the transmission oil:** Heavy PTO use tires the oil faster than standard use; work towards the lower limit of the level and change interval.
- **Keep the air system dry:** On vehicles where the dryer cartridge is not replaced on time, the solenoid valve and the piston seize because of moisture; most winter freezing faults originate here.
- **Preserve the propshaft angle and balance:** An angle changed during bodywork modifications begins to fatigue the PTO output shaft.
- **Take noise seriously:** A whine that has just started is usually the first and cheapest warning of a bearing or backlash problem.
- **Carry out periodic torque checks:** On bodywork subject to vibration the housing bolts loosen over time; an annual torque check prevents a significant proportion of leaks.

When the unit is damaged, replacing the PTO on its own is not always the right answer. If there are broken teeth, peened tooth flanks or heavy swarf, the countershaft gear must also be inspected; a new PTO fitted to a damaged countershaft gear returns to the same point in a short time. The correct approach is not to put the new part into service until the root cause of the failure has been closed out.

Frequently Asked Questions

What is a transmission PTO and what does it do?

A transmission PTO (power take-off unit) is a gear unit bolted to the transmission housing that takes its drive from the countershaft gear and transfers part of the engine power to the bodywork equipment. In applications such as tipper lifting, driving a hydraulic pump, cranes, mixers and compaction bodies it is the sole source of power. It is engaged not while the vehicle is driving but generally while it is stationary with the engine running.

The PTO does not engage, what should I check first?

The first check is not mechanical but pneumatic and electrical. The cab switch, the fuse, the supply to the solenoid valve and the air pressure at the solenoid outlet should be checked in that order. If pressure does not reach the working range, the fault is in the circuit; if pressure is present but the output shaft does not turn, the problem is inside the unit at the sliding gear or the piston. Frozen moisture in winter and a blocked air filter are among the most common simple causes.

Can the vehicle be driven while the PTO is running?

This depends entirely on the PTO type. Classic side mount, clutch dependent units are designed to be operated only while the vehicle is stationary; use while driving leads to gear damage. Sandwich type and split-shaft units used in applications such as mixers and sweepers, on the other hand, are designed to transmit power while the vehicle is moving. Which type is fitted to your vehicle should be verified from the bodywork documentation.

Why is backlash so important when fitting a PTO?

Backlash is the working tolerance between the PTO input gear and the transmission countershaft gear, and it is set by the thickness of the gasket pack. If the clearance is left too small, the gears heat up under permanent load and progress to fracture at the tooth root; if it is left too large, the tooth ends are peened under shock loading. The typical band is of the order of 0.10-0.35 mm, but the exact value is in the manufacturer's fitting instructions.

The PTO is whining, what does that mean?

A continuous whine that rises with speed usually points to one of three causes: incorrectly set backlash, a fatigued bearing or a low transmission oil level. The easiest and cheapest check is the oil level; if the level is normal, the swarf on the magnetic plug is inspected and the backlash is measured with a dial gauge. When a whine is ignored, it mostly ends in gear damage.

Does the transmission oil have to be drained when replacing a PTO?

The decision is determined by the position of the PTO aperture relative to the oil level. If the aperture is above the level, partial draining may be sufficient; otherwise the oil must be drained into a suitable container. Once assembly is complete, the level must be checked and topped up without fail; a PTO running without oil produces bearing and gear damage in a short time.

How do I choose the correct PTO speed ratio?

The speed ratio is calculated not from the engine of the vehicle but from the requirement of the bodywork equipment. The speed at which the hydraulic pump delivers the desired flow is

determined, this speed is expressed as a ratio of the working speed of the engine, and the catalogue ratio closest to the resulting percentage is selected. In heavy commercial applications this ratio is generally between 50 and 140 percent of engine speed. A wrong selection comes back either as insufficient lifting power or as early pump failure.

The PTO is leaking oil, does the whole unit have to be replaced?

Not every leak calls for a complete replacement. A leak between the housing and the transmission mostly comes from a crushed gasket or a slackened bolt, and renewing the gasket together with a torque check solves the problem. For a leak behind the output flange, seal replacement is the first step. However, if the leak is accompanied by whine, swarf or overheating, the damage goes beyond the sealing element and the unit as a whole must be assessed.

How long does a transmission PTO last?

Service life is measured in operating hours, not in kilometres. In short duty applications such as tippers the unit can give a life close to the major overhaul interval of the vehicle, whereas in mixer and sweeper applications that run for hours every day the maintenance interval becomes markedly shorter. The deciding factors are correct engagement habits, the condition of the transmission oil, the dryness of the air system and the backlash setting achieved during fitting.

How do I select the correct transmission PTO?

Vehicle model alone is not enough for selection. The type code on the transmission plate, the cover hole pattern (six or eight bolt), the output flange form, the direction of rotation, the required speed ratio and the necessary torque capacity must all be used together. If there is an OE reference number on the old unit, that is the most reliable starting point. Placing the new part side by side with the old one before fitting and comparing the hole pattern, shaft profile and housing depth is the final safety step.

VADEN ORIGINAL is a manufacturer of OE quality spare parts for heavy commercial vehicle braking, fuel and driveline systems. Our transmission PTO product family holds in stock power take-off units together with connection and sealing elements for trucks, tractor units and special bodywork applications, matchable by transmission type. You can search for the unit suited to your vehicle by transmission type code or OE reference number and place your order after verifying it against the compatibility data in the catalogue.